

### Error Codes and Checkpoints

Display*	Description	Diagnosis Point (Trouble Point)	Remarks
(F) 06	Low recirculation flow	Check return line filter.	Komano
	(Only Warning Indication)	<dedicated mode="" only=""></dedicated>	
	NOTE) Even though the unit is detecting recirculation flow, but the flow is not	Purge the air in the domestic not water line and return line. <crossover mode="" only=""></crossover>	
	enough for proper recirculation operation.	Check the crossover valve's filter	
(F) 10	Combustion abnormality	Check air supply vent for blockage or obstruction.	
	(Only memorized in error code history)	Check exhaust vent for blockage or obstruction. Have a professional check the gas supply pressure.	
		Check if the condensate drain line (clogged, frozen or slope down).	
(5) 11		Check the DIP switch settings on the circuit board.	
(F) 11	Ignition failure (Initial flame fault detection)	spark (12). Check Gas Valve (13). Check Flame Rod (10).	
		Check ground, paying special attention to the ground connection	
(5) 40	Flows Dod doos not dotost flows	to the Circuit Board.	
(F) 12	(Flame fault detection)	combustion. Check Gas Valve (13). Check Flame Rod (10).	
	× ,	Check ground, especially on Circuit Board.	
		from the vent pipe.	
(F) 13	External CO alarm triggered	Check for abnormal combustion.	
		Check all vent components are secure and fully connected. Check for any exhaust leaking from vent pipes	
		Check if CO alarm wire cut off.	
(F) 15	Abnormally high input	Measure the resistance through the Thermistor	
(5) 46	temperature	-Primary Heat Exchanger Inlet ( 6 ). Check gas type.	
(F) 10	temperature	Check for the offset pressure of the gas valve and gas type.	
(F) 20	High Limit Switch	Check if High Limit Switch-Primary Heat Exchanger is triggered	To reset this error code, the power needs to be
	-Primary Heat Exchanger triggered	(14). Check for improper connection of High Limit Switch-Primary	disconnected and then reconnected.
		Check if the Scale Build-up in the Heat Exchanger.(This error code	
		may be caused by Scale Build-up in the Heat Exchanger)	
(F) 30	Thermistor-Air abnormality	Measure the resistance through the Thermistor-Air (15).	
		Check for an open or short circuit. Check for improper connection of Thermistor-Air.	
(F) 31	Thermistor-Cold Water abnormality	Measure the resistance through the Thermistor-Cold Water (4)	
(. ,		Check for an open or short circuit.	
		Check for improper connection of Thermistor-Cold Water.	
(F) 32	Thermistor-Hot Water abnormality	Measure the resistance through the Thermistor-Hot Water ( 5 ).	
		Check for improper connection of Thermistor-Hot Water.	
(F) 33	Thermistor-Primary	Measure the resistance through the Thermistor-Heat Exchanger	
	Heat Exchanger Outlet abnormality	Outlet (7). Check for an open or short circuit.	
(5) 65		Check for improper connection of Thermistor-Heat Exchanger Outlet.	
(F) 35	Thermistor-Exhaust abnormality	Measure the resistance through the Thermistor-Exhaust ( 8 ).	
		Check for improper connection of Thermistor-Exhaust.	
(F) 36	Thermistor-Primary	Measure the resistance through the Thermistor-Heat Exchanger	
	Heat Exchanger Inlet abnormality	Inlet ( 6 ).Check for an open or short circuit.	
		Check for improper connection of Thermistor-Heat Exchanger Inlet.	
(F) 42	Water Flow Sensor (Recirculation)	Check voltage from Circuit Board (17).	
(F) 61	Fan Motor abnormality	Check that the fan is rotating and check the pulse frequency from	
		the fan rotational frequency sensor (11). Check for improper	
(5) 60		Connection of the fan. Check voltage from Circuit Board.	
(F) 63	(No recirculation Abnormality	<pre><dedicated mode="" only=""></dedicated></pre>	
	NOTE) The unit is not detecting recirculation	Purge the air in the domestic hot water line and return line.	
	flow.	Crossover mode only> Check the connector marked "Crossover" is closed	
		Check the crossover valve's filter	
(F) 65	Water Servo-Main	Check that the Water Servo-Main is functioning (1).	To reset this error code, the power needs to be
(5) 00	abnormality	Check for Improper connection of the valve.	disconnected and then reconnected.
(1) 66	abnormality	Check that the water Servo-Bypass is functioning (2).	disconnected and then reconnected.
(F) 70	Circuit Board abnormality	Circuit Board failure.	To reset this error code, the power needs to be
			disconnected and then reconnected.
(F) 71	Gas Valve drive circuit abnormality	Check for damage to the Gas Valve drive circuit on the Circuit	To reset this error code, the power needs to be
		Board.	disconnected and then reconnected.
(E) 72	Flame Rod circuit abnormality	Measure the current from the Elame Rod when there is no flowe	in the display continues, contact nearest agent.
(1)/2	(Detection of flame when no	(9).	
	flame is present)	Check for a ground fault.	
(F) 73	Circuit Board setting abnormality	Check for proper setting of maintenance writers on Circuit Board.	This error is displayed when switching the dip
	(Improper Maintenance Writers Settings, DIP Switch Settings, etc.)	Check the Circuit Board (microcomputer) for damage.	switch with the power on. To reset this error code, the power needs to be
		e.g.) Exhaust type, vent length, etc.	disconnected and then reconnected.
F76	Multi-system communication error	Check for proper connection of Quick Connect Cord.	
760	Remote Controller transmission	Check connection from Remote Controller to Circuit Board.	
(=)	abnormality	Check Remote Controller and Circuit Board for damage.	-
(F) 90	Combustion abnormality	Check air supply vent for blockage or obstruction.	To reset this error code, the power needs to be disconnected and then reconnected
		Have a professional check the gas supply pressure.	If the display continues, contact nearest agent.
		Check if the condensate drain line is clogged or frozen.	
		Check the dip switch settings on the circuit board.	
(F) 94	Exhaust temperature is too high	Check for abnormal combustion ( 8 ).	To reset this error code, the power needs to be
		. ,	disconnected and then reconnected.
(F) C1#	Service Reminder	This unit is equipped with a service reminder.	changer
# - 1-9		Excessive dust or lint build-up in the fan and air intake may affect ef	ficiency and combustion performance .
		Contact the phone number of instruction manual for additional inform	nation about recommended maintenance.

## Circuit Board Checkpoints

Ref. No.	Part	Cii (C be	rcuit I heck ehind	the wiring d the front co	ck points liagram over)		Normal value	Remarks	Remarks		
		CN & Pin	No.	Wire Color	CN & Pin	No.					
			12	W - O		7	DC 1 - 16 V				
			12	W - G		8	DC 1 - 16 V				
1	Water Servo-Main	CN59	12	W - V	CN59	9	DC 1 - 16 V				
			12	W - BK		10	DC 1 - 16 V				
			11	Y - BL		28	DC 1V or less	When valve is full	y open		
			1	W - O		3	DC 1 - 16 V				
			1	W - G		4	DC 1 - 16 V				
2	Water Servo-Bypass	CN59	1	W - V	CN59	5	DC 1 - 16 V				
			1	W - BK		6	DC 1 - 16 V				
			2	Y - BL		28	DC 1V or less	When valve is full	y open		
			30	R - BL		28	DC 14 - 16 V				
3	Water Flow Sensor	CN59	29	Y - BL	CN59	28	DC 0.5 - 15 V				
4	Thermistor-Cold Water	CN63	7	W - W	CN63	2	Note 1)	Note 1)			
5	Thermistor-Hot Water	CN63	1	W - W	CN63	2	Note 1)	Note 1)			
6	Thermistor-Primary Heat Exchanger Inlet	CN63	5	W - W	CN63	2	Note 1)	Note 1)			
7	Thermistor-Primary Heat Exchanger Outlet	CN63	8	W - W	CN63	2	Note 1)	Note 1)			
8	Thermistor-Exhaust	CN63	3	W - W	CN63	2	Note 2)	Note 2)			
0	Elama Bad	CNIZO	3	BL - Heat exchanger		GND	10 kHz - 100 kHz				
9	Fiame Rod	CN78	3	BL - Electrode	-	Flame Rod	DC 0.45µA or less	When no flame is o	letected		
10	Elama Bad	CNIZO	3	BL - Heat exchanger		GND	10 kHz - 100 kHz				
10	Fiame Rou	CIN76	3	BL - Electrode	-	Flame Rod	DC 1µA or more	At flame detect	tion		
			6	W - BL		4	DC 140 - 187 V				
11	Ean Motor	CN27	3	R - BL	0107	4	DC 13 - 16 V				
	Fan Motor		1	O - BL		4	DC 1.69 - 8.25 V	When fan is rotating			
			2	Y - BL		4	208Hz - 1300 Hz	12 pulse/revolu	tion		
12	Igniter	CN42	6	W - BK	CN1	2	AC 108 - 132 V	When igniter is sp	arking		
12	Gaa Valva	CN110	1		CN10	2	DC 90 - 120 V	When valve is c	pen		
15	Gas valve	CINIO	'	R - DL	CNIU	2	1.22 kΩ - 1.50 kΩ	Coil resistance	Note 4)		
14	High Limit Switch -Primary Heat Exchanger	CN42	1	BK - W	CN1	1	$1\Omega$ or less	Contact resistance Note			
15	Thermistor - Air	CN63	6	BK - W	CN63	2	Note 3)	Note 3)			
16	Recirculation Pump	CN42	3	W - BK	CN1	2	AC 108 - 132 V	When Pump is w	orking		
	Water Flow Sensor		30	R - BL		28	DC 14 - 16 V		-		
17	(Recirculation)	CN59	27	Y - BL	CN59	28	DC 0.5 - 15 V				
-	Power Supply (Power Circuit Board)	CN92	3	W - BL	CN92	4	AC 108 - 132 V				
-	Power Supply (Power Circuit Board)	CN92	1	W - BK	CN92	2	AC 108 - 132 V				
-	Remote Controller	CN89	1	BL - BL	CN89	3	DC 14 - 16 V				

Note 1) •Cold Water / Hot water / Primary Heat Exchanger Inlet / Primary Heat Exchanger Outlet Thermistor Temperature Characteristics

Temperature (° F)	32	50	68	86	104	122	140	158	176
Temperature (° C)	0	10	20	30	40	50	60	70	80
Resistance (k Ω)	23.7	15.5	10.3	7.0	4.9	3.5	2.5	1.9	1.4
Voltage (V)	4.5	4.3	4.0	3.6	3.2	2.8	2.4	2.0	1.7

Note 2) •Thermistor - Exhaust Temperature Characteristics

Temperature (° F)	-4	14	32	50	68	86
Temperature (° C)	-20	-10	0	10	20	30
Resistance (k Ω)	487	276	162	98.3	61.4	39.5
Voltage (V)	4.6	4.3	3.9	3.4	2.8	2.3

Note 4) When measuring the resistance, disconnect the connector from circuit board and check the connector side.

Note 3) •Thermistor - Air Temperature Characteristics

Temperature (° F)	-4	14	32	50	68	86
Temperature (° C)	-20 -10		0	10	20	30
Resistance (k Ω)	101.7	57.7	33.8	20.4	12.6	8.0
Voltage (V)	4.4	4.0	3.5	2.9	2.3	1.7

Refer to appliance's installation manual or reach out to our customer care, if more information is needed.

Contact details are available on the rating plate of the appliance.

\*In a Quick Connect Multi-System, "F##"(except F76) indicates an error code from the secondary unit (unit without a remote controller).

## Displaying Maintenance Monitors

<Display Procedure>

 Press and hold both the Up [▲] and Down [▼] Buttons simultaneously for more than 2 seconds. This can be done regardless of whether the power has been turned on or the unit is operating.

<Indications>

- 1. The maintenance monitor data No. will appear on the display for two seconds, and then the data will appear.
- In order to switch to other maintenance monitor data, press either the up or down button once. The data No. will then reappear, then different data No. can be selected using the Up [▲] and Down [♥] Buttons.
- When the maintenance monitor data No. is changed, the data No. will be displayed for two seconds, after which the data will appear.
- 3. With the Remote Controller in maintenance mode, the hot water set temperature and Settings cannot be adjusted.

#### <Returning to Normal Mode>

1. To return to normal mode, press and hold both the Up [▲] and Down [▼] Button simultaneously more than two seconds, or leave it alone for more than 10 minutes.

#### Remote Controller



### When setting the maximum temperature to 125-140°F (55-60°C)

- 1. Turn the unit off by pressing the Power ON/OFF Button on the Remote Controller.
- 2. Press and hold the Setting Button until a sound is heard (2 sec.) and 120 °F (50 °C) appears on the display.
- 3. Set the upper limit of the hot-water supply temperature to 125°F, 130 °F, 135 °F or 140 °F (55 °C or 60 °C) using the Up [▲] and Down [▼] Buttons.
- 4. To put the unit back into operation, press the power ON/OFF Button on the Remote Controller. To keep the unit off, let the unit sit for 30 sec. to return to the original display.

## DIP Switch Settings

Disconnect the electrical power to the water heater before adjusting the DIP Switches.

The following settings can be adjusted using the DIP Switches:

- 1. To set up with the common vent system, SW 1 needs to be turned on.\*
- 2. By using SW 2 and 3, it can adapt to the setting of the exhaust type.\*\*
- By using SW 5 and 6, adjustments can be made for use at high elevation.
   By using SW 7 and 8, adjustments can be made for extended vent lengths.
- Refer to the "Setting list for DIP Switches" table for details.

#### Setting list for DIP Switches

SW1	SV	/2	SW3	SV	V5	SW6	SW7		SW8
Common vent system*	Ex	haust	type**	Ele		vations above 2000ft Adjustmer			: Length and Vent Size
SW1	SW2	SW3		SW5	5 SW6 High Elevation Adjustment		SW7	SW8	
OFF	OFF	OFF	DV	OFF	OFF	0~2000ft (0~610m)	OFF	OFF	2" Short Length
ON	ON	OFF	OD	ON	OFF	2001~4000ft (611~1219m)	ON	OFF	2" Long Length
	OFF	ON	SV	OFF	ON	4001~7000ft (1220~2134m)	OFF	ON	3" Short Length
	ON	ON	EZTR	ON	ON	7001~10000ft (2135~3048m)	ON	ON	3" Long Length

\* Refer to the Installation Manual of common vent system for detail information.

\*\* DV : Direct Vent, OD : Outdoor (using VC-6), SV : Single Vent (using SV Conversion Kit), EZTR : 2" PP Flexible Pipe (using EZ2-CK)

## Adjusting Gas Valve Offset Pressure

Use the following procedure to adjust the gas valve offset pressure:

- 1.Shut off the main gas supply valve.
- 2.When the gas valve offset pressure is adjusted, remove the front cover.
- Because it is not possible to adjust the gas valve offset pressure with the front cover attached. 3.Remove the 9/32" hex head/Philips screw from the Gas Supply Pressure port on the Inlet Gas Connection
- and connect the manometer or pressure gauge using a silicon tube.
- 4.Loosen the screw of Offset Pressure Port on the gas valve and connect the manometer or pressure gauge using a silicon tube. For dual port manometer, use the positive pressure side.
- 5.Open the gas supply valve and operate the unit.
- 6.Press and hold both the "Mode" and "Minimum" buttons on the Circuit Board simultaneously for more than 3 seconds.
- After releasing your fingers, the low fire condition will last 30 minutes. 7. If gas valve offset pressure adjustment needed, remove the cap of gas valve, and then adjust the gas offset pressure by turning the set screw no more than 1/8 turn.

Circuit Board

8.After offset pressure adjustment, do not forgot to tighten the 9/32" hex head/Philips screw to the Gas Supply Pressure Port.To return to the normal operation, press and hold the "Mode" button for more than 3 seconds.



\* Gas offset pressure values are subject to change without prior notice Check the latest burner specification table.



Gas Supply Pressure Port





### Maintenance Monitor List

6

Data	Item	(Display Reading	X Multiplier)	Value for	Rema	rks			
02	Total Blug in Time	Multiplier	Unit	Indication	Disp. Banga [000] [1310]				
03		× 100	hour	100 nour	Disp. Range [000] - [1310]				
04	Total Combustion Time	X 1	nour	1 nour	Disp. Range [000] - [999]				
05	Total Combustion Time	X 1000	nour	1000 hour	Disp. Range [000] - [003]				
00	Number of Institute Times	X 100	nour	100 nour	Disp. Range [000] - [1999]				
07	Number of Ignition Times	X 10	time	10 times	Disp. Range [000] - [999]				
80	Number of Ignition Times	X 10000	time	10000 times	Disp. Range [000] - [065]				
10	Fan Rotational Frequency	X 10	rpm	10 rpm					
11	Service Reminder Hours Accumulated(1)	X 1	hour	1 hour	Disp. Range [000] - [999]				
12	Service Reminder Hours Accumulated(1)	X 1000	hour	1000 hour	Disp. Range [000] - [065]				
14	Total Flow Rate	X 0.1	gal/min	0.1 gal/min			*1		
		X 0.1	L/min	0.1L/min			*2		
17	Recirculation Flow Rate	X 0.1	gal/min	0.1 gal/min			*1		
		X 0.1	L/min	0.1L/min			*2		
18	Output (%)	X 1	%	1 %					
20	Calculated Fan Speed	X 10	rpm	10 rpm					
21	Service Reminder Hours Accumulated(2)	X 1	hour	1 hour	Disp. Range [000] - [999]				
22	Service Reminder Hours Accumulated(2)	X 1000	hour	1000 hour	Disp. Range [000] - [065]				
29	Reason why the unit does not run.				[001]: Water inlet temperatu → If possible decreas [002]: Calculated water outle → If possible increase [004]: Inlet and Outlet tempe → Check the pipes an	re is too high e water inlet te et temperature flow rate rature are reve id re-install it c	emperature is too high ersed orrectly		
	Thermistor-Cold Water	X 1	°F	1°F			*1		
30	Detection Temperature	X 0.1	°C	0.5°C			*2		
	Thermistor-Hot Water	X 1	°F	1°F			*1		
31	Detection Temperature	X 0 1	°C	0.5°C			*2		
	Thermister Primary Heat Exchanger	X 0.1	°F	1°F			*1		
32	Outlet Detection Temperature	X 0 1	°C	0.5°C			*2		
	Thermister Primery Heat Evenenger	X 1	°E	1°E			*1		
33	Inlet Detection Temperature	× 1	°C	1°C			*2		
	The resistor Exhoust	× 1	о С	1°E			×1		
36	Detection Temperature	× 1	F	1.6			*2		
		× 1	0 0 0 0	10	Dian Banga (014) (050)		×1		
38	I hermistor-Air Detection Temperature	× 1	F	11F	Disp. Range [014] - [050]				
		X 1	°C	1°C	Disp. Range [-10] - [010]		^2		
50	FF NoPrimary Heat exchanger	X 0.1		0.1					
51	FF+FB NoPrimary Heat exchanger	X 0.1		0.1					
52	Output-Primary Heat exchanger	X 0.1		0.1					
53	Output-Total	X 0.1	0100	0.1	[000]/(mm) [1700]/(loop)				
60	Position of Water Servo-Main	X 2	Step		[000](open) - [1700](closed)				
62	Position of Water Servo-Bypass	X 2	Step		[000](open) - [1700](closed)				
65	Number of Pump Operation Times	X 1000	time	1000 times					
66	Initial Recirculation Flow	X 0.1	gal/min	0.1 gal/min	Memorized recirculation flow rate as	initial recirculation	condition. *1		
		X 0.1	L/min	0.1L/min	Memorized recirculation flow rate as	initial recirculation	condition. *2		
78	Flame Lifting Detection				OFF [0-0], ON [0-1]				
80	Remaining Time of Scale Flushing	X 1	minute	1 minute	[000] - [060]				
82	Number of Scale Flushing Times	X 1	time	1 times	[000] - [255]				
						Dedicated Mode	Crossover Mode		
					Auto Recirc (Default)	11	21		
86	Recirculation Mode				Manual Timer Recirc	12	22		
					Always Recirc ON	13	23		
					Always Recirc OFF	14	24		
					On-Demand (Title24) Mode	15	25		
87	Circuit Board ID1: Product 1	[1:xy]			A=101,B=102,C=103, · · ·	,Z=226			
88	Circuit Board ID2: Product 2	[2:xy]			A=201,B=202,C=203, · · ·	,Z=326			
89	Circuit Board ID3: Version	[3:xy]			A=301,B=302,C=303, · · ·				
91	Error Code History 1	Most Recent E	Error Code						
92	Error Code History 2	Next Most Recer	nt Error Code		1				
93	Error Code History 3	Next Most Recer	nt Error Code		If the same error code is the	nantad			
94	Error Code History 4	Next Most Recer	nt Error Code		it will appear in the history li	the same error code is repeated, will appear in the history list			
95	Error Code History 5	Next Most Recer	nt Error Code		twice. If it is repeated more than				
96	Error Code History 6	Next Most Recer	nt Error Code		twice, it will only appear twi	ce.			
97	Error Code History 7	Next Most Recer	nt Error Code		1				
98	Error Code History 8	Next Most Recer	nt Error Code		-				
 98 Endi Code History 8					1				

# [DIP Switches ]

12345678

OFF ON

		Unit				
Recirculation Mode/	Crossover	Ν	Naintenan	Required Additional		
Recirculation Timer	Connector	22	23	24	3B	пеш
①External / Auto (Default)	OFF	OFF	OFF	OFF	OFF	Nothing
②External / On Demand (TT24)	OFF	ON	ON	OFF	ON	On Demand Switch
③External / Manual	OFF	ON	OFF	ON	OFF	RC-9018M
④External / Always (24hrs)	OFF	OFF	ON	OFF	OFF	Nothing
⑤Crossover / Auto	ON	OFF	OFF	OFF	OFF	Cross Over Valve
6 Crossover / On Demand (TT24)*	ON	ON	ON	OFF	ON	Cross Over Valve, On Demand Switch
⑦Crossover / Manual	ON	ON	OFF	ON	OFF	Cross Over Valve, RC-9018M
⑧Crossover / Always (24hrs)**	ON	OFF	ON	OFF	OFF	Cross Over Valve, RC-9018M
(9)No Recirculation*** (Pump Always OFF)	OFF	ON	ON	OFF	OFF	Nothing

Possible to set 6, but the unit behaves as 5.

\*\* Not recommended Recirculation Mode because of the unit can't detect Reirculation failure.

\*\*\* If a customer uses RC-7651M (residential remote), can stop recirculation without Maintenance Writer changing. See the Owner's Guide for detail information.

> \*1 When Remote Controller is in °F/Gallons mode. \*2 When Remote Controller is in °C/Liters mode.